

Supporting guidance for Ditch Blocking – Peat Dams

This is an old version of the page

Date published: 20 January, 2023

Date superseded: 3 October, 2023

For recent changes to this guidance, please see the [bottom of the page](#).

Planning Permission

The Town and Country Planning Amendment Order introduced new permitted development rights under Class 20A for peatland restoration projects. This means that anyone proposing to carry out peatland restoration works such as ditch blocking must first notify the relevant planning authority through the '[prior notification/prior approval](#)' process.

The planning authority should reply to you with their decision within 28 days. If they do not reply within 28 days then no further action is required.

An AECS contract cannot be issued until this process has been completed, so we advise you to notify planning at AECS application stage, then update the case officer as your case is being assessed.

Choice of dam – peat dams or plastic piling?

Peat dams should be considered the default technique to block ditches or moor grips. They are much cheaper to install than dams made of other materials, especially where a large number of dams are required. Peat dams work well on shallow peat where plastic dams cannot form a watertight seal.

Peat dams are only successful in peat with a shallow slope. Peat dams cannot include an overflow and are made of soft material. If the gradient is too steep the water flow can cause erosion over the top of the dam resulting in failure. Where dams need to be installed on the sloping edges of bogs, we recommend you use plastic piling.

You can build peat dams by hand in ditches of up to 70 centimetres wide and 60 centimetres deep. Machine-built dams can be in ditches up to 150 centimetres wide and 120 centimetres deep, depending on the peat composition. Above these dimensions, the peat dam structure can become unstable particularly if flow rates are high.

Siting of dams

Careful planning is required to correctly locate active ditches, estimate the correct number of dams required and where these should be placed in order to effectively block a ditch. Certain locations, such as dry peat banks should be avoided.

Best practice guidance suggests that dams should be placed one every 15 metres. The precise intensity of damming depends on the flow of water in the ditch, the slope and the amount of water held back by each dam. Aim for the final water level to be at the surface or no more than 20 centimetres below the peat surface. The distance between dams should be such that there is one dam per 25 centimetres drop in ground level.

Methods

Peat dams can be constructed by hand or machine digging. Careful planning is more important for machine digging as access to bogs and availability of machinery can be limiting. You should state which method you propose to use in your Ditch Blocking Plan.

Each individual peat dam must be installed to the full depth and width of the grip, in accordance with the dam construction requirements below.

If, during year four, more than 10 per cent of the dams are not holding water, you must repair or replace them (adjacent to existing dam).

Producing a plan

When submitting your application you should include a Ditch Blocking Plan. You should state in your plan what methods you are using and you should state why these have been selected. Include details of the number and locations of the ditches and dams.

If you are producing another management plan, for example a Moorland Management Plan, it may be appropriate to include details of your ditch blocking work as a sub-section of this plan.



[Ditch Blocking Plan \(MS Word, Size: 199.9 kB\)](#)

doc_external_url: https://www.ruralpaymentsandservices.org/media/resources/AECS-update-2022---Ditch-Blocking-Plan---Jan-22_1.docx [Plan template]



Ditch blocking with peat dams – Credit: Andrew McBride, NatureScot

Related management options

- [Lowland Bog Management](#)
- [Wetland Management](#)
- [Moorland Management](#)

Related capital items

- [Ditch Blocking – Plastic Piling Dams](#)
- [Matting to Prevent Damage to Bogs](#)
- [Moving or Realigning Ditches](#)

Futher information

Detailed information on how to install peat dams is available from the [Peatland Action page](#) of the NatureScot website.

Recent changes

Section	Change
Top of page	New section added covering Planning Permission

Previous versions

[Previous versions of this page](#)

[Download guidance](#)

Click 'Download this page' to create a printer-friendly version of this guidance that you can save or print out.